



LEGEND

- AC AUTOMATIC CUTOFF
 - MC MANUAL CUTOFF
 - DS DISCONNECT SWITCH
 - CONTACTOR COIL
 - HEATING ELEMENT
 - TR TRANSFORMER
 - CONTACT NORMALLY OPEN
 - FUSE
- CONTROL 24V: RED WIRE
POWER: BLACK WIRE

WARNING:
Disconnect all supplies before working on this duct heater

IMPORTANT:
Wire in according with electrical codes
Use copper wire for 90°C minimum

NOTE:
All wiring outside this frame are wiring by others

PROPRIETARY INFORMATION: THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION & IT'S PROPERTY OF N.E.P. LTD. THIS DOCUMENT AND THE INFORMATION IT CONTAINS SHALL NOT BE DUPLICATED OR USED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF N.E.P. LTD.